



USER MANUAL



SV 103

DAILY VIBRATION EXPOSURE METER

Warsaw, 2023-11-20
Rev. 1.01

Copyright © 2023 SVANTEK.
All rights reserved.



Note: The **SV 103** instrument contains no user serviceable parts. Opening product case invalidates the warranty.



Note: Battery power indicator - To improve accuracy of remaining battery life indicator, run the instrument until it is fully discharged; then proceed with a full charge via the micro-USB port. The procedure is recommended before first use. Repeat this procedure every few months of use to maintain more accurate current battery condition indication.



Note: Because of continuous product improvement SVANTEK reserves the right to make changes to product specifications without notice. To download the most up to date user's manual please visit our web site at www.svantek.com.

This user's manual presents the firmware revision named 1.15.x (see the Unit Label review to check version details).

This user's manual presents some aspects of SUPERVISOR software revision named 1.4.4 (see the software start-up splash screen).

The succeeding software revisions (marked with the higher numbers) can change the view of some displays presented in the text of the manual.



WEEE Notice: Do not throw the device away with the unsorted municipal waste at the end of its life. Instead, hand it in at an official collection point for recycling. By doing this you will help to preserve the environment.

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

Copyright © 2023 Svantek Sp. z o.o.

All rights reserved.

Reproduction without permission is prohibited.

Trademarks

Trademarks or registered marks in this manual belong to their respective manufacturers.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Svantek.

Svantek provides this document "as is", without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Svantek reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Svantek assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information:

web: www.svantek.com,

DECLARATION OF CONFORMITY

INSTRUMENTATION FOR SOUND & VIBRATION
MEASUREMENTS AND ANALYSIS

**CE Declaration of Conformity**

No. SV103-CE-EN/07/2019

Manufacturer: **SVANTEK Sp. z o. o**Address: Strzygłowska 81
04-872 Warszawa
Poland


Kind of product: PERSONAL HUMAN VIBRATION EXPOSURE METER

Type: **SV 103**Directive: **Low Voltage Directive (LVD) 2014/35/EU**

Standard: EN 61010-1:2010 Safety requirements for electrical measurement equipment

Directive: **Electromagnetic Compatibility Directive (EMC) 2014/30/EU**Standards: EN 61326-1:2013 Measurement equipment: EMC emission and immunity
EN 55011:2016 Radio-frequency disturbance characteristics - Limits and methods of measurement (CISPR 11:2015)**Auxiliary industry standards:**ISO 8041-1:2017 Human response to vibration – Measuring instrumentation
EN ISO 5349-1:2001 Human exposure to vibration – General requirements
EN ISO 5349-2:2001 Human exposure to vibration – Practical guidance

I, the undersigned, representing the manufacturer, declare in sole responsibility, that the product specified above, to which this declaration relates, conforms to the above mentioned Directives and Standards:

Place of issue: **Warsaw, Poland**Date of issue: 26 07 2019**Wiesław Barwicz, General Manager**
(signature)**SVANTEK Sp. z o. o.****www.svantek.com****e-mail: office@svantek.com.pl****Headquarters:**

Strzygłowska 81, 04-872 Warsaw, Poland

tel./fax: +48 22 51 88 320; +48 22 51 88 312

VAT EU PL5270105272

REGON 002175672

KRS 000192065

Registered in the Warsaw District Court, XII Economic Department

Initial Capital 100 000 PLN

CONTENTS

DECLARATION OF CONFORMITY	3
1 INTRODUCTION	6
1.1 Vibration risk and it's assessment	6
1.2 SV 103 as a new generation vibration exposure meter	7
2 SV 103 SYSTEM DESCRIPTION	8
2.1 SV 103 key features	8
2.2 Kit components	8
2.3 Related equipment & accessories	9
2.4 Instrument Software (Firmware) options available	9
3 GETTING STARTED	10
3.1 SV 103 control panel	10
3.2 Input output interfaces description	10
3.3 Mounting of the SV 103 vibration exposure level meter	11
3.4 LED status indicator	12
3.5 Status bar icons	12
3.6 Manual control of the instrument	12
3.6.1 Primary key functions	13
3.6.2 Alternate key functions	14
3.6.3 Alternate combined keys function	15
3.7 Charging	15
3.8 Turning on/off	16
3.9 Starting and stopping measurement run	17
4 RUNNING AND OPERATING BASIC PROCEDURES	18
4.1 The VIEW mode presentation concept	18
4.1.1 Running RMS view mode	18
4.1.2 Primary "ONE-RESULT" parameters view mode	18
4.1.3 Results for channels view mode	19
4.1.4 OCTAVE analysis spectrum view mode	19
4.1.5 Instrument Status view mode	20
4.1.6 File information view mode	21
4.2 ALARM screen review	21
4.3 Reviewing unit label	21
4.4 Loading Measurement Setups	22
4.5 Calibration and verification of the instrument	22
4.5.1 Instrument calibration	23
4.5.2 Verification the Instrument's calibration	24
4.5.3 Checking the contact forces transducer	25
4.6 Auto-run mode information	26
4.7 Security lock	26

4.8	Measurement procedures	27
4.9	Reviewing measurements	27
5	BASIC OPERATIONS WITH THE PC SOFTWARE	28
5.1	Installing and connecting to PC	28
5.2	Main software window	29
5.3	Instruments inventory panel	30
5.3.1	Manage the instrument options	31
5.4	Configuration setup	32
5.4.1	Working with configuration setup files	32
5.4.2	Measurement parameters settings tab	34
5.4.3	Triggering settings tab	36
5.4.4	Time-history data logging settings tab	37
5.4.5	Display VIEW configuration tab	38
5.4.6	General settings tab	39
5.4.6.1	Security settings panel	39
5.4.6.2	Auxiliary settings panel	40
5.4.7	Auto-Run settings (timer, pauses) tab	41
5.4.8	Signal recording options tab	42
5.4.8.1	Recording on trigger	42
5.4.8.2	Continuous recording	42
5.5	Working with data files	43
5.5.1	Downloading instrument files	43
5.5.2	Local files "Data Browser"	44
5.6	Working with sessions and reporting	44
5.6.1	Force threshold slider	47
5.6.2	Report panels	47
6	SV103 MAINTENANCE	51
6.1	General recommendations for use	51
6.2	Cleaning	51
6.3	Changing the accelerometer	51
6.4	Firmware upgrade	51
6.5	Storing the instrument	52
6.6	Transportation and carrying	52
7	SVANTEK SERVICE	53
7.1	Troubleshooting	53
7.2	Resetting the instrument	53
8	SV 103 TECHNICAL SPECIFICATION	55

1 INTRODUCTION

1.1 Vibration risk and it's assessment

During human contact with the surface of the vibrating machine, mechanical vibrations are transmitted directly to the human body, affecting the individual tissues or even the whole body. Vibration that affects humans is called human vibration and is divided into whole-body and hand-arm vibration.

In practice, the most dangerous are hand-arm vibrations which can cause pathological changes in the nervous, vascular (cardiovascular) and osteoarticular system. Hand-arm vibration occurs when one or both of the upper limbs is in contact with a vibrating surface. Typical sources of such vibration are any kind of hand tools that generate vibration, steering wheels and levers to control vehicles. The characteristic feature of hand-arm vibration is their **variability in time**. Therefore, very often, measurement results depend on the point in time that measurement takes place. This is a very important feature that defines both the test methods and measurements describing this kind of vibration. This variability in time influences another significant factor in determining the body's response to the vibration which is the exposure time (duration of exposure to vibration).

The fundamental parameter used in the evaluation of hand-arm vibration is the vector sum of tri-axial vibration called AEQ which is the basis for the calculation of daily exposure A(8). To identify the daily exposure, it is necessary to identify all the sources of vibration, which means identifying all working modes of tools (e.g. drilling with hammer and without), and changes in the conditions of use of the device. This information is necessary for the proper organization of measurement and to include as many common tasks of the operator during which he is exposed to hand-arm vibration. Daily exposure should be calculated for each source of vibration.

After determining the sources of mechanical vibrations affecting the employee, the next step is to choose the most appropriate accelerometer mounting. According to ISO 5349, hand-arm vibration should be measured in place, or at the point of contact with the hand tool. The best location is the centre of the handle which is the most representative location. ISO 5349 suggests using lightweight sensors to reduce measurement errors. Measurements directly at the hand are performed using special adapters and measurement in all three axes is recommended.

Typical vibration exposure consists of short periods in which the operator is in contact with the tool. Measuring time should include a representative tool operation time and the measurement should start from the moment the vibrating device is touched and should end when the contact is broken, or the vibration stops (ISO 5349-2:2001).

1.2 SV 103 as a new generation vibration exposure meter

SV 103 is the first ever made personal hand-arm Daily Vibration Exposure Meter (DVEM). Instrument meets ISO 8041-1:2017 standard and it is an ideal choice for the measurements according to ISO 5349. SV 103 is typically attached to the user's arm. Similarly, to noise dosimeters, the SV 103 daily vibration exposure meter is small enough not to interfere with working activities. New technology of SV 107 accelerometer gives advantages such as shock resistance, no DC offset effect, very low power and frequency response down to DC. Inside the hand adapter is the latest MEMS accelerometer and a contact force sensor.

Contact forces act between the hand and the vibrating surface: the push/pull force and the gripping force. Studies on the hand-arm vibration prove that contact forces modify exposure to vibration and the health effects it causes the need of simultaneous assessment of the contact forces and vibration magnitudes has been universally recognized and reflected in ISO 15230.




Figure 1-1 Examples of contact forces measurement given by ISO 15230

The high-resolution colour OLED screen displays information in both text and graphical form and offers excellent visibility in dark sites as well as in full daylight conditions.

Using the computational power of its digital signal processor the SV 103 instrument can simultaneously measure the all results (**RMS**, **Max**, **Peak**, **Peak-Peak**, **Vector**, **A(8)**, **Dose**, **ELV**, **EAV**) simultaneously in three channels and perform real time 1/1 Octave or 1/3 Octave analysis.

Advanced time history logging provides safe and complete information about measured signal in the internal large 8GB memory.

The instrument is powered from internal new generation Ni-MH rechargeable batteries offering circa 30 hours of continuous operation. The powering and charging of the instrument from the USB interface is provided which also enables easy data exchange connection between **SV 103** and a PC without the requirement of a special docking station.

The instrument works with "Supervisor" PC software which allows instrument configuration, measurement results viewing and exporting as well as daily vibration exposure recalculation.

2

SV 103 SYSTEM DESCRIPTION

2.1 SV 103 key features

- Hand-arm Personal human vibration meter conforming to ISO 8041-1:2017 standard
- Measurement under gloves
- **SV 107** hand-arm triaxial MEMS accelerometer including hand straps according to ISO 5349-2:2001
- **OLED colour display** with super brightness and contrast
- Large **8GB memory**
- **USB 2.0** high speed interface
- In order to comply with ISO 5349-1:2001, the input signals from all measurement channels are frequency weighted with the **Wh** weighting filters and corresponding Band Limiting filter
- Digital true RMS detector with Peak detection, resolution 0.1 dB
- Frequency Range **1 Hz ÷ 2 kHz**
- Measurement range **0.2 ms⁻² RMS ÷ 2000 ms⁻² Peak**
- Simultaneous measurement results: **PEAK, P-P, RMS, CExp, A(8), EAVTT, AEVTL, ELVTT, ELVTL, OVL, AEQ**
- **3** user configurable measurement channels
- Easy in use **predefined setups**
- **Time-history** data logging of **PEAK/P-P/RMS/Vector/Force** with variable 0.1 s to 1 h logger step for three channels
- **Time-domain** signal recording (optional)
- **1/1 octave** or **1/3 octave** real time analysis (option)
- Operational time **> 30 hours** (*display off, octave analysis off*)
- Extremely **compact, lightweight and robust case with IP65 ingress protection**: dimensions 88 mm x 49.5 mm x 19.2 mm, weight 150-160 grams with SV107 accelerometer and one of vibration contact adapters

2.2 Kit components

- **SV 107** – hand-arm triaxial accelerometer for SV 103 instrument including hand straps
- **SC 156** - micro-USB 2.0 cable
- **CD with instruction**
- **Built-in rechargeable batteries** (charger/ power supply wall adapter not included)

The below figure shows the SV 103 standard set and way of mounting.



Figure 2-1 SV 103 standard mounting set

2.3 Related equipment & accessories

Accessories

- **SA 54** – Charger/power supply for 1 x SV 103
- **SA 156** – USB HUB for charging and data download from 5 x SV 103 instruments
- **Supervisor Software** for configuration, viewing and exporting data, USB drivers (MS Windows XP, Vista, Windows 7) for 32- and 64-bit operating systems available as freeware

Related equipment and accessories

- **SV 111** – Vibration calibrator for in-situ check to ISO 8041-1:2017
- **SA 73** – Carrying case for SV 103 instrument and accessories (waterproof)

2.4 Instrument Software (Firmware) options available

- **SF 103 OCT 1/1** – 11 band 1/1 octave real time analysis option
- **SF 103 OCT 1/3** – 34 band 1/3 octave real time analysis option
- **SF 103 WAV** – Time domain / Wave recording option



Note: The software options can be purchased in any time as only the introduction of a special code is required for their activation.

3 GETTING STARTED

3.1 SV 103 control panel

The below figure shows the SV 103 controls and ports:



Figure 3-1 SV 103 view

3.2 Input output interfaces description

SV 103 is equipped with a set of useful interfaces:

- accelerometer connector (essential for measuring)
- micro-USB connector (charging, and data download)
- charging connector (reserved for future use)
- fast infrared port (reserved for future use)




Figure 3-2 SV 103 side view – accelerometer and micro-USB connector

charging
connector



infrared
port

Figure 3-3 SV 103 back view - charging and infrared port (reserved for future use)

3.3 Mounting of the SV 103 vibration exposure level meter

SV 103 should be attached to the arm of the operator and the accelerometer mounted on the hand.



Figure 3-4 Typical mounting of SV 103 on an operator's arm

The transducer is supplied with 3 adapters of different shape. Before measurements, select the appropriate shape adapter to the projected work, and unite it with the transducer using screws. The transducer should be mounted on the hand with the cable in the direction of the elbow as pictured. The cable is to be secured with a mounting band on the wrist not interfering with working activities.



Figure 3-5 Mounting the adapter on the hand

3.4 LED status indicator

There is a three-colour instrument LED status indicator on SV 103, located to the right of the accelerometer mounting head and above the display. Table below explains conditions under which the specific LED colour appears.

LED status indication	Description
GREEN flashing once per second	Indicates the instrument is running and has not exceeded the alarm level.
AMBER flashing once per over a dozen seconds	Indicates the instrument is stopped and has not exceeded the dose alarm level.
RED flashing quickly , four times per second	Indicates the alarm conditions : for instance: the dose has exceeded the alarm level.

3.5 Status bar icons

The upper part of the display is designed as basic status information provider. See the description below.




Figure 3-6 SV 103 display icons description

3.6 Manual control of the instrument

Although the Instrument is small, its keypad is designed to be minimal, but still highly ergonomic and easy to use providing effective operational capabilities. Thanks to that, the number of the control keys of the instrument is reduced to only three.

Generally, the user can operate the instrument by:

- change the **VIEW** mode with the **<ENTER>**  key
- select the required **VIBRATION AXIS** with the **<AXIS>**  key
- and **SCROLL** thru the results with the  or  keys



Note: To save power consumption and extend battery life SV 103 will automatically switch off the display after 30 seconds if no button on the keypad is pressed. The LED indicator will still inform the user about the current state of operation and any possible alarm conditions. Press any key, to reactivate the display.

3.6.1 Primary key functions

On the front panel of the instrument the following control keys are located. See below for primary (short press) key functions description:




Figure 3-7 Control keypad on the front panel – primary key functions

The **<SCROLL>**  or  keys allow to:

- scroll down thru results in the **RESULTS VIEW** modes
- move cursor left and right in the **SPECTRUM VIEW** modes
- scroll down and up thru menu **Calibration** positions
- scroll down and up thru setups in the **Load Setup** menu
- decrease and increase the values of the **Level** parameter in the **Calibration axis** screens
- reject or confirm Warnings or other confirmation messages.

The **<ENTER>**  key allows to:

- change **VIEW** modes
- enter different positions in the **Calibration** screens
- confirm changed parameters (for example, **Level** parameter in the **Calibration axis** screens).

The **<AXIS>**  key allows to:

- change presented vibration channels
- escape from **Load Setup** and **Calibration** screens.

3.6.2 Alternate key functions

Alternative **long press of single key** (keypad icons marked with red colour) allows quick access to special functions:

- **POWER ON/OFF** the unit by holding down the **<ENTER>**  key
- **Calibration** menu activation by holding down the **<SCROLL>**  key
- **LOCK** keypad and screen by holding down the **<SCROLL>**  key
- **SETUP** loading by holding down the **<AXIS>**  key










Figure 3-9 Control keypad on the front panel – alternate key functions

Holding down individual key for few seconds a countdown is displayed. If you release the key too early, SV 103 returns to the last used **VIEW** mode and the selected control is not executed.

3.6.3 Alternate combined keys function

Additionally, **combined short press of two keys simultaneously** allow quick access to even more functionalities:

- **Start/Stop** measurement by pressing the **<SCROLL>**  and  keys simultaneously
- Enter **Pause** screen by pressing the **<ENTER>**  and **<SCROLL>**  keys simultaneously during the measurement run
- Enter **Units** screen by pressing the **<SCROLL>**  and **<AXIS>**  keys simultaneously
- Enter **Unit Label** screen by pressing the **<AXIS>**  and **<ENTER>**  keys simultaneously



3.7 Charging

SV 103 is equipped with an internal charger, so that the fixed internal batteries can be charged directly from USB port or optionally provided charger (**SA 54**).

Ensure that SV 103 is fully charged prior to use by connecting it to a USB port or to USB charger. Ensure the power supply is connected and the supply is switched on. SV 103 will automatically switch on during charging and display how much charge is within the instrument. SV 103 will display 'Fully charged' once charging is complete. This should take approximately 6 hours from a fully discharged state. A charging time of about 2 hours will be sufficient to perform greater than 8 hours of measurement. A fully charged instrument holds enough charge to run for approximately 30 hours.

Note that once disconnected from USB power supply, the instrument will automatically switch off. If returned to the USB connection or put again onto the docking station the instrument keeps trickle charging regardless of whether or not it is fully charged. This keeps the battery performance in steady condition. If the battery is fully discharged prior to being placed on a charger, SV 103 trickle charges for a short time prior to the fast charge cycle, this prevents damage to the batteries.



Note: To charge a fully discharged battery, it would take approximately 4-6 hours. Note also, that instrument under charging condition is slightly warm. It is normal state for NiMH type cells and does not affect the measurement accuracy.



Note: To charge multiple units at the same time via the USB port, ensure your computer or possibly the powered USB hub such as SA 156 or switch is capable in terms of providing enough current performance. Standard hub or switches without external power supply are not capable to charge multiple SV103 units due to insufficient current supply.

Current estimation: Assume the current consumption on 0.2A level and calculate required power supply requirement ($N \times 0.2A$).

Power wattage estimation: With nominal voltage of 5V per USB, the power supply wattage should be 1.0W per unit ($N \times 1.0W$).

For example, 5 units charged at once require: 1.0A/12.5W USB power supply

For example, 3 units charged at once require: 0.6A/7.5W USB power supply

For example, 1 unit charged alone requires: 0.2A/2.5W USB power supply.



Note: Use only high-quality USB cables. Many poor-quality cables do not ensure low resistance of the cable, thus disabling proper charging of the internal cells.

3.8 Turning on/off

TURNING ON: To switch the power on the operator should hold the **<ENTER>**  key for a couple of seconds. The instrument switches on and goes the self-test routine (during this time the manufacturer's logo, the name of the instrument and firmware version is displayed).

Then SV 103 will enter the stopped (ready to measure) mode and enter the running instantaneous RMS mode if enabled.



Note: Warm up time - After power on, the instrument should be warmed up for at least 60 seconds before starting measurement.




Note: If you leave the instrument in stopped (ready to measure) mode, the display will be switched off after 30 seconds, and the unit will turn off after some period of no keypad activity to save the batteries. The above-mentioned period can be program and is set up for 1 hour by default.



Note: SV 103 will show a warning screen if the battery capacity is below 2 hours of potential measurement time.

TURNING OFF: To shut down the unit the operator should hold the **<ENTER>**  key for a couple of seconds during which a countdown ("Shutting down" 3... 2... 1...) is displayed. Thus, SV 103 gives you time to decide if you really want to turn off the instrument. If you release the key too early, SV 103 returns to the last presented **VIEW** mode.

If enabled in the configuration setup there may be presented an additional, double-check, warning screen. This is for the operator to be aware and convinced the unit is really to be turned off.





Note: If **auto-run** (timer) mode is active, SV 103 will automatically stop the measurement when the set time is over and then turn off. If no **auto-run** mode is used and specific time has not been pre-set, the unit will continue to measure until the battery is exhausted. Just before switching off, the measurement run will be stopped and all data until that point will be saved securely for later download to the PC.

3.9 Starting and stopping measurement run

START:

Before starting a measurement ensure that:

- 1 the instrument is turned on,
- 2 there is sufficient battery operating life and free memory by checking the status screen,
- 3 the required configuration setup selected,
- 4 SV 103 is calibrated, because it affects the results.

To start the measurements the user has to press the **<SCROLL>**  and  keys at the same time. The results of the measurement are displayed in the last used result's display view mode. One profile mode is always available for most Functions of the instrument. The results of the measurements can also be presented in other display modes, which can be enabled or disabled and adjusted to the user's needs.

STOP:

The same combination of keys: **<SCROLL>**  and  allows the user to stop the measurement run. All run results are always saved automatically, there is no need to save them manually.

After stopping the measurement run, make sure that:

- 1 the data to PC for further analysis is download,
- 2 the instrument turned off.

4 RUNNING AND OPERATING BASIC PROCEDURES

4.1 The VIEW mode presentation concept

Such an advanced vibration instrument as the **SV 103** offers a large number of parameters for the operator to inspect. Therefore, all information is divided in neatly organized manner as **VIEW** modes for each channel.

The **VIEW** mode is a way in which the measurement parameters are presented to the operator. In other words, when you change the **VIEW** mode, specific measurement parameters and status information will be presented in different manner as distinct screen content.

SV103 features the following **VIEW** modes, where most of them can be individually disabled:

- Running RMS for three channels view mode
- Primary “one-result” parameters view mode - *cannot be disabled*
- Results for channels list view mode
- 1/1 and 1/3 octave analysis RMS spectrum view mode
- 1/1 and 1/3 octave analysis spectrum MAX view mode
- Instrument Status view mode
- File Information view mode

4.1.1 Running RMS view mode

Running RMS presentation mode is used when measurement run is not actually running, that is when the instrument is in standby mode before or after a measurement. In this mode the current RMS results for all channels are calculated and displayed, but not stored in the instrument's memory. The purpose of this information is to give the user a first indication of the vibration levels about to be measured. The instrument behaves as a simple general-purpose vibration level meter in this view mode.




Figure 4-1 Running RMS view mode screen

4.1.2 Primary “ONE-RESULT” parameters view mode

The one result mode is always available in all measurement modes and cannot be disabled. In one result mode any measurement result, selected via **<SCROLL>**  or  key, may be presented. The user may change the actual channel view by pressing **<AXIS>**  key. This view mode is useful if in low vision conditions or is suitable for operators with some visual impairment.




Figure 4-2 Primary parameters view mode screen

4.1.3 Results for channels view mode

To get information about a number of results at one time it is handy to switch to the “results list” view mode. Up to three parameters at a time are accessible for the operator.



Figure 4-3 Results list view mode screens

4.1.4 OCTAVE analysis spectrum view mode

If enabled, the instrument operates as a 1/1 or 1/3 octave band real time analyser (RTA). In addition, and if enabled, 1/1 or 1/3 octave analysis is performed in parallel with the exposure level meter operations. All 1/1-octave digital pass-band filters (with 11 centre frequencies from 1 kHz down to 1 Hz; in base two system) or 1/3-octave digital pass-band filters (with 34 centre frequencies from 1.6 kHz down to 0.8 Hz; in base two system) are working in real-time with the RMS detector for all three channels.



Note: The two overall TOTAL RMS results are measured with the weighting filters (**Wh** and **BL(Wh)**) without taking into account the settings of the instrument for channels. The spectra are always linearly averaged.

The results of 1/1 and 1/3 octave analysis (so-called spectrum) can be examined by the user on a display in Spectrum VIEW presentation mode. 1/1 and 1/3 octave spectra for all centre frequencies of pass-band filters together with the 2 total overall values measured with the **Wh** and **BL(Wh)** frequency weighting filters are presented in the Spectrum mode if enabled in configuration setup. Spectrum cursor can be moved left and right with **<SCROLL>** , **<SCROLL>**  keys respectively.




Figure 4-4 1/1 and 1/3 octave analysis spectrum graph RMS view mode screens




Figure 4-5 1/1 and 1/3 octave analysis spectrum graph MAX view mode screens

4.1.5 Instrument Status view mode

Instrument **Battery** view presents:

- the battery charge status
- estimated working time which is Left until the battery is expected to be completely drained
- and current **Setup** information

Instrument **Battery** screen is moved down and up with <SCROLL>  and  keys respectively.



Figure 4-6 Instrument Battery view mode screens




Note: Battery state of charge calculation is based on internal charge counter and should be considered only as an overall, not very precise, determined estimation. Therefore, the time left could be noticeably different. Although the newest technology cells are used the slight degradation over time is inevitable thus aging requires occasionally factory based (or authorised service centre) replacement of the rechargeable battery cells.



Note: Battery power indicator - To improve accuracy of remaining battery life indicator, run the instrument until it is fully discharged; then proceed with a full charge via the micro-USB port or docking station. The procedure is recommended before first use. Repeat this procedure every few months of use to maintain more accurate current battery condition indication.

4.1.6 File information view mode

Instrument **File information** view presents current file name and size.



4.2 ALARM screen review

Apart from simple LED alarm indications there are two alarm conditions (EAV and ELV), when ALARM presentation screens will appear. During a measurement run the **SV 103** will immediately turn on the display at the time that the programmable alarm condition is exceeded. Press any key, to confirm the information.





Note: At any time when battery power is almost exhausted the “low battery” alarm screen may inform you about immediate recharging requirement.

4.3 Reviewing unit label


Unit Label screen is accessed by pressing the **<AXIS>**  and **<ENTER>**  keys simultaneously and provides information about elementary instrument properties such as:

- Copyrighted manufacturer name: SVANTEK
- Instrument name: SV 103
- Unit serial number: SN ...
- Accelerometer serial number: SN(SV107) ...
- Unit name: **John_Smith** [user programmable name]
- Firmware version: 1.06.02
- CRC(OK): BBB8
- Standards list, that instrument conforms to ISO 8041-1:2017



Unit Label screen is moved with **<SCROLL>**  or  keys.


To exit the **Unit Label** screen just short press the **<ENTER>**  or **<AXIS>**  key. Then **SV 103** will return to the last presented **VIEW** mode.



Note: The personalized **Unit Name** can be set arbitrarily with SUPERVISOR software.

4.4 Loading Measurement Setups


Press and hold **<SCROLL>**  key. The “Load Setup” menu will appear with the list of loaded configuration setups to choose.



To abandon setup selection, press the **<AXIS>**  key. Otherwise select the required configuration setup with **<ENTER>**  key navigating thru the list with **<SCROLL>**  or  key. The following screen will appear, allowing you to confirm that you really want to load the selected setup, or to cancel the selection and return to the configuration setup list.



Press **<SCROLL>**  key to cancel the setup loading, or **<SCROLL>**  key to confirm loading selected setup configuration.



Confirming the loading of configuration setup leads to the screen with status of the loading procedure.

After successfully setup loading it is possible to return back to the list of predefined setups by pressing the **<SCROLL>**  key or go further to measurement screen by pressing the **<SCROLL>**  key.


4.5 Calibration and verification of the instrument

Three levels of performance testing are defined in ISO 8041-1:2017 International Standard:

- Pattern evaluation (targeted at manufacturers): A full set of tests, to be performed on samples of an instrument type. Pattern evaluation may be used for product type testing or pattern approval of vibration measuring instruments. The objective of these tests is to demonstrate an instrument design can meet the specifications defined in this International Standard.
- Periodic verification (targeted at manufacturers and users): An intermediate set of tests to be performed periodically (e.g. prior to, or at the time of purchase, and every 1 or 2 years thereafter) to verify that the performance remains within the specifications of this International Standard, to demonstrate that one-off instrument systems comply with the requirements of this International Standard, and following modification or repair that may affect the performance of the instrument.
- In-situ check (targeted at users): A minimum level of testing, indicating that an instrument is likely to be functioning within the required performance specification. These tests shall be carried out immediately before and after measurements are made.

The SV 103 instrument is offered with the dedicated SV 107 hand-arm accelerometer. It makes the calibration very easy by direct usage of commonly available vibration calibrators. The instrument is factory calibrated with the supplied accelerometer.

SV 103 is equipped with both periodic verification (**By Measurement** calibration) and in-situ check (**System Check**) functions, which can be run from the **Calibration** menu. The Calibration menu is opened by holding down the **<SCROLL>**  key.





Note: The manufacturer's recommended factory calibration interval is every 12 months for this instrument to be confident in its continuing accuracy and compliance with the international specifications. Please contact your local SVANTEK distributor for further details.

4.5.1 Instrument calibration

To calibrate the instrument the user has to perform next steps:


1. Select **By Measurement** position in the **Calibration** menu and press the **<ENTER>**  key, select the appropriate channel (axis X, Y or Z) and press the **<ENTER>**  key again.




2. Adjust the actual calibration level of the calibrator to be used with the **<SCROLL>**  or  keys. The **Factor** position demonstrates the current calibration factor.



3. Mount the calibration adaptor on a shaker table.
4. Mount the accelerometer on calibration adaptor and tighten it up with screw
5. Switch on the calibrator and wait ca 30 seconds for its stabilisation before starting the calibration measurement
6. Start the calibration measurement by pressing the **<ENTER>**  key. Delay before starting calibration measurement is counted down on the display.




The calibration measurement lasts minimum 30 second and stops until the same result is obtained 3 consecutive times. It is possible to stop the calibration measurement by pressing the **<AXIS>**  key. After the measurement, its result is presented on the display.




It is recommended to repeat the calibration measurement a few times. The obtained results should be almost the same (with ± 0.1 dB difference). The reasons for the unstable results are as follows:

- the calibrator is not properly attached to the instrument
- there are external vibration disturbances
- the calibrator or the measurement channel is damaged.

7. Press the **<ENTER>**  key in order to accept the measurement result.



Note: If a calibration factor does not meet tolerance criteria the unit informs the user and proposes to exit the calibration measurement without saving its results.



Post calibration. If enabled, the post processing is performed automatically under acceptance of calibration measurement.



Note: If it is required to perform so called post-calibration of the instrument (in case the Post Calibration is pre-programmed within configuration setup) SV 103 automatically adds the calibration factor to the header of the result files. This doesn't modify the saved results and gives the user to possibility to compare the possible changes of accelerometer sensitivity before and after the measurements.





Note: The calibration factor is always considered in all instrument's function (like 1/1 Octave or 1/3 Octave analysis).


4.5.2 Verification the Instrument's calibration

To check (verify) the calibration factor, the user has to:


1. Select **System Check** position in the **Calibration** menu and press the **<ENTER>**  key, select the appropriate channel (axis **X**, **Y** or **Z**) and press the **<ENTER>**  key again.




2. Adjust the actual calibration level of the calibrator to be used with the **<SCROLL>**  or  keys. The **Factor** position demonstrates the current calibration factor.




3. Mount the calibration adaptor on a shaker table.
4. Mount the accelerometer on calibration adaptor and tighten it up with screw
5. Switch on the calibrator and wait ca 30 seconds for its stabilisation before starting the calibration measurement
6. Start the measurement by pressing the **<ENTER>**  key. Delay before starting measurement is counted down on the display.



The measurement lasts minimum 30 second and stops until the same result is obtained 3 consecutive times. It is possible to stop the measurement by pressing the **<AXIS>**  key.



After the measurement, its result is presented on the display. The user can now check if the result of the measurement is close enough to the calibration level.



7. Press the **"Exit"** in order to return to the **System Check** screen.

4.5.3 Checking the contact forces transducer



Note: The SV 107 is currently supplied with the force transducer calibrated at the factory and this force transducer can only be checked by the user. Previous versions of the SV 107 allowed the user to calibrate the force transducer. The instrument recognises the SV 107 version and offers the check functionality as described below or calibration for older transducers. If the SV 107 does not have the contact force transducer, the instrument will not offer either check or calibration functionality.



The check should be performed every time the SV 107 hand straps are changed. As reference level, the user can use a simple bathroom scale.




Figure 4-7 Using a bathroom scale as reference level for the contact force check

To check the contact force transducer, the user has to:

1. Select **Check force** position in the **Calibration** menu and press the **<ENTER>**  key.



2. Press the scale as shown in the figure above and compare the readings on the scale and on the instrument.



Note: The instrument displays contact force readings in Newtons (N), so please convert Newtons to kgf using the equation: $1 \text{ N} \sim 0,1 \text{ kgf}$.

4.6 Auto-run mode information

Note, that when auto-run mode (timer and/or pause) is configured, there is information on the screen available for the user. There is no need to turn on the instrument manually. All the timer procedures can be easily pre-programmed with the use of the **SUPERVISOR** software.




Figure 4-8 Auto-run mode – timer and programmable pause screen

4.7 Security lock

Locking the keypad and display during the measurement serves to prevent from tampering with the measurement run. That automatically prevents any tampering, but the unit can still be unlocked, if necessary, with proper sequence of key presses.

The programming of lock/unlocking function of the instrument can be done via the SUPERVISOR software (see chapter [5.4.6](#) “General settings tab”).

Locking SV 103 unit:

SV 103 can be set up to automatically go into locked mode when it starts. For this purpose, the “**Lock During Measurement**” position in the SUPERVISOR software should be set to **On**.

It is always possible to lock the instrument manually. In this case the user should hold the **<SCROLL>**  key for a couple of seconds during which a countdown (“Keyboard lock” 3... 2... 1) is displayed and the unit gives you time to decide if you really want to activate security lock. If you release the key too early, SV 103 returns to the last presented **VIEW** mode.

Unlocking SV 103:

There are two ways for unlocking the instrument, which can be programmed via the SUPERVISOR software.

If “**Unlock on Key**” position in the SUPERVISOR programme is set to **Off**, SV 103 can be unlocked without providing Lock/Unlock sequence. Simply hold the **<SCROLL>**  key for a couple of seconds during which a countdown (“**Keyboard lock**” 3... 2... 1...) is displayed.

If the “**Unlock on Key**” position in the SUPERVISOR programme is set to **On**, SV 103 can be locked/unlocked by providing Lock/Unlock keys sequence.

To unlock the unit the user has to press the keys in the correct sequence.



Figure 4-9 Unlocking the unit sequence screens

4.8 Measurement procedures

Preferably, when taking measurements, the vibration instrument should be attached to the employee at the start of a shift and collected at the end of the whole shift. In case a shorter period is sampled then care should be taken to ensure that the result is representative of the full shift exposure. Shorter sampled periods require that the sampler has a deep and full understanding of the expected working tasks during the shift and the duration cycles of those tasks.

Before performing any vibration measurements, ensure that employees selected for evaluation are operating equipment or performing tasks under normal (representative) conditions, and emphasise the importance of continuing to work in their usual manner (wearing the instrument should not interfere with normal duties). Explain the purpose and procedures of sampling to the employee who will be wearing the instrument and the importance of not touching, tapping or interfering with it. Instruct the employee not to remove the instrument unless absolutely necessary.

The general procedure for taking measurements could be as follows:

1. Check that the indicated instrument battery life is at least twice the time required for the measuring period.
2. Check the instrument setup mode is appropriate and change if necessary.
3. Check the calibration of the instrument and adjust the settings if required.
4. Secure the instrument onto the employee's arm selected for sampling.
5. Start the recording session manually if it is not programmed for an automatic timed start.
6. At the end of the measurement period, stop the recording session, and remove the instrument from the employee.
7. Follow your organisation's specific procedure for personal vibration exposure recordings analysis.
8. Ensure the report is submitted to the appropriate person
9. Distribute copies of vibration exposure recordings to test participants and explain the results.

4.9 Reviewing measurements

Most of the results can be inspected in real-time during either measurement run or stopped mode of operation. If the display screen is turned off just press any key (but watch notice below).

The keys on the keypad of the instrument enable you to navigate thru most of the parameters. For specific information on the VIEW modes.

- Use the <SCROLL>  or  keys to move thru the measurement results
- Use the <AXIS>  key to change the channel you would like to inspect
- Use the <ENTER>  key to change the VIEW mode



Note: In most cases the keypad will be probably locked. To gain access to the results and unlock the keypad see chapter [4.7](#).



Note: After reviewing results remember to lock the keypad again in order to maintain the integrity of the measurement run by preventing uncontrolled access to the instrument.

5

BASIC OPERATIONS WITH THE PC SOFTWARE

This chapter explains data storage, the configuration setup of the instrument, and how to customize the parameters via the “Supervisor” PC software.

With use of micro-USB cable, software, and SV 103, it is easy to:

- set up required configuration parameters and download these, so called **SETUPS**, straight to the SV 103 instrument
- retrieve time history data to view and analyse your vibration recorded charts, graphs, with extended reporting functionality.



Note: In case of detailed description of the Supervisor software functions, please refer to the Supervisor user manual.

5.1 Installing and connecting to PC

Insert the **Supervisor** software CD/DVD into your PC and run the installation program. After installation we are ready to connect the SV 103 instrument.

- Plug the USB cable into the computer.
- Plug the opposite end of the cable (micro USB) into the instrument itself.
- SV 103 is powered and charged directly through the computer; thus, you do not need separate charger. The instrument screen will be switched on automatically with current charging information only.
- Turn on the instrument - long press of the **<ENTER>**  key.
- The user should install drivers for Svantek instruments if not previously installed.
- Once switched on, run the **Supervisor** software.



Figure 5-1 Supervisor splash screen



Note: Supervisor software enables communication with multiple instruments. Therefore, with the use of a USB hub such as SA 156 it is pretty straightforward to connect all of them at the same time.

5.2 Main software window

The main screen of the SUPERVISOR is divided into few panels. Panels expose areas of interest of professional users and satisfy user's needs to find, configure, download, review and assess stored data in a very simple but still professional way.

- Control panel enables you to select: Instrument control, Data browser or Session you work with.
- Instrument filter enables SV 103 device selection, or other Health and Safety dedicated instruments.
- Inventory panel detects all SV 103 connected devices (see chapter 5.3).
- Quick access file manager enables you to copy configuration setup files between computer and instrument internal memory (see chapter 5.4.1).
- Instrument configuration panel enables access to all measurement run configuration settings (see chapter 5.4.1 for details).




Figure 5-2 Supervisor main window

5.3 Instruments inventory panel

Click the **SV 103** big instrument icon in the left “Instrument filter” Panel to get access to the devices.

Inventory panel ([Figure 5-3](#)) enables you to see all currently connected, or previously connected instruments of the same type. There are a number of columns with information related to each particular instrument related to the correct allocation of instrument and calibrator calibration report details.

“Settings”
configure setup files and the instrument”

“Download”
download measurement data from the device

small clock update icon button

configurable columns
right click on top menu row

possible context operations
right click on instrument row

Connected	Instrument	Clock	Mem.	Firmware ver.	Setup activation	Activated setup	Cal. validity date	Instrument Cal. report
Yes	SV 103 #3500	2014-06-28 10:38:33	N/A	1.06.2	2014-06-20 10:15:29	Settings	N/A	

Instrument files
Selected: SV 103 #3500

Local files
Selected: None

Context menu (right click on top menu row):

- Refresh catalogue
- Set Clock
- Edit name
- Manage options/functions
- Edit calibration info
- Add instrument calibration report
- Add calibrator calibration report
- Look for new firmware
- Send 'clear setup' command

Configurable columns (right click on top menu row):

- Name
- ✓ Clock
- ✓ Free memory
- ✓ Firmware version
- Last setup upload date
- Last uploaded setup name
- ✓ Last setup activation date
- ✓ Last activated setup name
- Instrument calibration certificate
- ✓ Calibration validity date
- Calibrator Serial Number
- ✓ Instrument Calibration Report
- Calibrator Calibration Report

Figure 5-3 Inventory panel and its capabilities

There are two control buttons near the Inventory Panel top menu:

- Settings button enables to configure current local configuration file, that can be later uploaded to the SV 103 instrument.
- Download button enables to navigate and download files directly from the instrument.




Note: To download any setup, or data file, first click the row related to the chosen instrument.


5.3.1 Manage the instrument options

The user may add new purchased options or functions to the instrument. For this purpose, it is necessary to know the activation code. Once the activation code is submitted the customer should follow the next steps to activate the new function:


- right click on the Instrument row and select the **Manage options/functions** position in the list,
- in the **Manage instrument options/functions** window select your option and click on **Unlock** button,



- key in the code in the opened **Enter code:** window and press **Ok**,



- the unblocked function is now enabled in the instrument current Settings.



Note: The above algorithm unblocks the function in the instrument, but not switches it on. To be able to change settings of newly unblocked function the user has to download the current Settings file from the instrument to the computer, select the new function and appropriate settings and upload new Settings file to the instrument.

5.4 Configuration setup

Customizing and saving set-ups are performed via the Supervisor. The following sections discuss each of the setup screens and explain how to save and send the parameters to the multiple instrument(s).

Settings described here apply to the type of **SV 103** model. If you are also using other instruments and have them connected, they will appear in the Inventory section panel, but no device will appear unless you first select the appropriate model picture on the left side of the application in instrument filter section. The clicked instrument picture denotes that the models are selectable from inventory panel when setup changes are applied and the “send setup to instruments” is selected.

To gain access to settings window click the “**Settings**” button near the Inventory panel (see chapter [5.3](#)).

5.4.1 Working with configuration setup files

The idea behind the configuration setup is to download the configuration setup file from the instrument to the computer you are working on and referred as “**Local files**” destination. Then it is possible to modify the settings and save with a custom name.




Figure 5-4 Setup files manager panel

For example: To download current settings file from SV 103, modify it, save with custom name, send it back to the device, export the setup to USB flash memory, and make sure the uploaded settings are applied in the instrument follow the presented procedure described below.

Once connected and selected in the inventory panel ([Figure 5-3](#)) the **SV 103** instrument is ready for the operation:

1. Select the **"Settings"** row position in left side panel named **"Instrument files"** (Figure 5-4).
2. Click the right arrow pictogram to download instrument **"Settings"** configuration setup to **"Local files"** right side panel (Figure 5-4).
3. Select the just copied **"Settings"** with a click: this will display quite a few configuration tabs on the right side so called Instrument configuration panel of the main **Supervisor** window (Figure 5-2).
4. Go through all the tabs to verify or change required parameters of the measurement runs. Follow the chapters from 5.4.2 to 5.4.8 to understand and configure the instrument.
5. Once configured, come back to setups file manager (Figure 5-4) and click the just edited **"Settings"** in **"Local files"** panel.
6. Next click the "save" button in bottom area of the panel (Figure 5-4).
7. To change the name right click on the selected row, and choose **"Rename"** command, which enables you to input a custom name for the setup that has just been edited (see the figure below).
8. To export the setup file, right click again on the selected row to open context menu and select the **"Export"** command (see the figure below). This will open standard save file window, where you can choose the USB flash memory disk, and save the configuration file to use on a different PC. Note, it is also possible to import the previously saved settings file to re-use a created setup configuration.




Figure 5-5 Exporting the configuration setup file

9. Now it is time to upload the configuration back to the instrument. Just click the left arrow pictogram.
10. Once copied select the copied file in the Instrument files, and right click onto it to open context menu. Then choose **"Apply"** command (Figure 5-6). Alternatively, you can enter the **"Load Setup"** menu directly in the instrument and load it as the current configuration. See chapter 4.4 for details.




Figure 5-6 "Instrument files" panel and context commands

11. This ends the procedure. Disconnect the instrument and the instrument is now ready for a new measurement run using the settings you have just uploaded.



Note: During configuration there are quite a number of parameters to set. To understand detailed meaning of parameters and how the results are calculated refer to Appendix D and check the following by chapters.

5.4.2 Measurement parameters settings tab

The main settings where specific vibration configuration can be set are located under the **Dosimeter** tab. There are already predefined pre-set fields with grey text. Other fields must be setup by the user.

Within the **Dosimetry** tab you can choose in which mode of operation the SV 103 should work: **Dosimeter**, or **Dosimeter** with 1/1 or 1/3 octave analysis.



Note: Enabling octave analysis shortens battery life, so take it into consideration and double check the battery status before measurement run.




Figure 5-7 Dosimetry configuration settings tab

Other basic parameters configurations are as per figure provided below:

- The **Start Delay** parameter defines the delay period from the moment the **<Start/Stop>** button is pressed to the start of the actual measurements (the digital filters of the instrument constantly analyse the input signal even when the measurement is stopped). This delay period can be set from **0 second** to **5 minutes**.
- The **Start Sync.** parameter defines maximum delay period from pressing the **<Start/Stop>** button to the start of the measurements to allow synchronisation with the instrument's RTC. The **Start Sync.** parameter can be set as: **Off, 1m, 15m, 30m** and **1h**. For example, if **1h** was selected, then each measurement starts from the first second of next real time hour after pressing **<Start/Stop>** key, and then each hour after **Integr. Per**, if **Rep. Cycles** is greater than one.
- The **Integration Time** parameter (integration period) defines the period during which the signal is being measured (integrated) and stored as the set of **Summary Results**.
- The **No. of Measurements** parameter defines the number of cycles (with the measurement period defined by **Integration Time**) to be performed by the instrument. The **No. of Measurements** number values are within the limits [1, 1000] of infinitive (**Inf.**).
- The **Standard** parameter defines the limits of **Exposure Action Value (EAV)** and **Exposure Limit Value (ELV)** for the measurements of the hand-arm vibration, which are obligatory in: England, German, France, Italy and Poland. It is possible to define also User limits.
- The **Exposure Time** parameter defines the desired value of the workday exposure time that is used for the calculation of the hand-arm Dose results.
- The **Alarm** parameter defines whether to set the alarm for **EAV** or/and **ELV**.
- The **FL+threshold** (Force under threshold) parameter defines total time during the measurement when the grip strength is less than the value defined in this position.

5.4.3 Triggering settings tab

To enable triggering measurement and logger go to the “**Triggering**” settings tab and switch on these functions by selecting triggering Mode: **Slope+**, **Slope-**, **Level+** or **Level-**.




Figure 5-8 Triggering settings tab

The **Measure Trigger** position activates or deactivates the measure trigger function. The **Logger Trigger** parameters define the way the measurement results are saved in the logger.

If **Slope +** is selected, the measurement starts when the rising result value (**Source**) passes above the level determined by the selected decibel **Level**. If **Slope -** is selected, the measurement starts when the falling result value (**Source**) passes below the level determined by the selected decibel **Level**. The measurement is stopped when the conditions set in the **General Settings** sub-list are fulfilled or after pressing the **<Start/Stop>** key or after receiving the proper control code remotely.

If **Level +** or **Level -** is selected for the measurement or logging the triggering condition is checked every 1 millisecond. The measurement or logging is recorded only when the result value (**Source**) has the greater / lower level than that determined in the **Level** position otherwise the measurement or logging result is skipped.

The **Source** of the triggering signal can be defined as one of or all channels of tri-axial accelerometer: **X**, **Y**, **Z**.

The level of the triggering signal (**Level**) can be set in the range from 80 dB to 180 dB.

The user may also select the number of the results saved in the logger before the fulfilment of the triggering condition (**Pre**) and the number of the results saved in the logger after the fulfilment of the triggering condition (**Post**). If the triggering condition is fulfilled, the logger contains:

- the measurement results registered directly before the fulfilment of the triggering condition. Time of this recording can be calculated by multiplying the value set in the position **Pre** by the time period taken from the **Logger Step** position,
- all measurement results up to the moment the triggering condition disappears,
- the results registered directly after the moment the triggering condition disappears. Time of this recording can be calculated by multiplying the value set in the **Post** position by the time period taken from the **Logger Step** position.

In the **Pre/Post** line the number of the results recorded in the logger's file before or/and after the fulfilment of the triggering condition can be set. This number is within the limit 0..6 for **Pre** trigger and 1..200 for **Post** trigger.

5.4.4 Time-history data logging settings tab

To enable logging time-history data go to the “**Time History**” settings tab and switch the very first switch button on the left panel.

- In the **left panel** named “**Time History Setup**” there are basic configuration fields related to: how frequently do you want to log the parameters, what name the logger file should have, and if extended summary results should be saved.



Note: Summary results are saved on “**Integration Period**” basis (not on “**Logger Step**” time). See Figure 5-7 how to set “**Integration Period**” parameter.

- **Right panel** named “**Display Results**” is accessible only if “**Logger**” switch button is set to “**On**”. You have the ability to choose, which basic results for each channel should be logged during measurement run and saved in internal storage memory.




Figure 5-9 Time History (logger) settings tab

5.4.5 Display VIEW configuration tab


As mentioned in chapter [4.1](#) there are quite a few VIEW modes accessible on the display, when the instrument is performing a measurement run.

- In the **left panel** named “**Modes & Views**” you can select which VIEW mode will be present when you press the **<ENTER>**  key on the instrument keypad



Note: The “ONE-RESULT” is the only VIEW mode that is always present and cannot be disabled.

In this panel you can also switch on the automatic screen off function (**Auto off**), which saves the energy of internal power source, the display rotate function, which positions the screen text always horizontally. You can choose the units of the displayed results in the position Units as **Logarithmic**, **Linear Metric** or **Linear Non-Metric**.



- In the **right panel** named “**Display Results**”, you will find a list of twenty measurement parameters, that can be configured to be presented on the SV 103 display, when you press **<SCROLL>**  and  key. See Appendix D to review acronyms for each parameter.




Figure 5-10 Display VIEW configuration tab

5.4.6 General settings tab

General settings tab concerns to many different usability options: See the followed by chapters to understand exactly how to configure these instrument settings.




Figure 5-11 General settings tab

5.4.6.1 Security settings panel

The security setting enables you to protect access to the instrument when in use with a simple keypad password to prevent users from inadvertently terminating a measurement run. This feature is set through the Supervisor's **"General"** settings tab.

To turn on the security option: switch on **"Lock During Measurement"** button. Once turned on, SV 103 will disable the keyboard every time, the measurement run is started.

See the chapter [4.7](#) how to lock and unlock the SV 103 instrument.

If **"Unlock on Key"** is set to **On**, SV 103 will require special code to be input by pressing four keys defined in this panel in a particular sequence.

If **"Unlock on Key"** is set to **Off**, SV 103 can be locked/unlocked without providing Lock/Unlock sequence.

Simply hold the **<SCROLL>**  key for a couple of seconds during which a countdown (**"Keyboard lock"** 3... 2... 1...) is displayed and the unit gives you time to decide if you really want to activate/deactivate the security lock. If you release the key too early, the operation will be cancelled.





Figure 5-12 Keyboard security settings panel

5.4.6.2 Auxiliary settings panel

Under auxiliary settings panel it is possible to:

- Set the calibration level and enable to perform additional calibration after a measurement session and add the results to the file saved in the memory. In the panel below, there are three options for saving results: not to save “Off”, save in the last file “**Last File**” or save in the files which will be created after last calibration (“**Files after last calibration**”).



- Enable additional warning screens to be displayed under certain conditions:
 - “**Logging disabled**” it warns the operator that time history results will not be stored
 - “**Power off**” additional confirmation just before switching off
- Set the **Reference Level** for the results presentation in logarithmic units
- Set **Time To Automatic Shutdown** the instrument
- To change menu **Language**, displayed on the screen of the instrument. The default language is English.




Figure 5-13 Auxiliary settings panel

5.4.7 Auto-Run settings (timer, pauses) tab

The **Auto-Run** panel enables the user to program the internal real time clock to act as a delayed start and stop timer. The instrument can be switched on by itself at the pre-selected programmed time and it can then perform the measurement run, which was used before it was last switched off. Auto-run feature is useful if you wish to pre-set the instruments to run and stop for a specific time period, such as a week-long study.




Figure 5-14 Auto-run configuration tab

The timer configured in right panel named **Timer** can be:

- switched off – **Off**
- switched on – **On**

In the case the timer function is active (**On**) and the instrument is switched on the **Time** screen appears until the programmed measurement runs are finished.

Setting hour and day of the measurement's start

The **Start (hh:mm)** and **Stop (hh:mm)** positions determines the time for the measurement to start and to stop automatically. The required hour and minute should be selected.

The **Day of week** determines the days in a week when the measurements should start. The timer can be programmed (**Max. no. of day**) up to 100 days ahead or without limitation (**Inf**) and during these days, settings of the current state of the **Real Time Clock** are taken into account. Make sure to check that the real time clock settings for the measurement location are correct before beginning a delayed timer measurement.

There is also possibility to program five independent **PAUSES** in the form of real time programming. See [Figure 5-14](#) for detailed settings in magnified area.

5.4.8 Signal recording options tab

Signal recording is an optional function, which should be unblocked. Signal recording can be performed as **Time Domain** recording to the same file as main and history results or as a separate **Wave** file. Both modes are mutually exclusive functions, and the one option should be turned off in order to enable the other one. The difference is that the **Time Domain** signal is recorded to the logger file, while **Wave** signal is recorded as a separate PCM file (or file in extensible format).

Both recordings may be configured in different “**Recording Mode**”. The signal may be recorded during whole measurement time (**Continuous** or **Whole Measurement**) or may be triggered with Slope or Level trigger.

5.4.8.1 Recording on trigger

It is possible to define three sources of triggering condition (**Trigger Source**) from all channels. Four last parameters define: level of signal for triggering (**Trigger Level**), pre-trigger recording (**Pre-Trigger**), time of recording after triggering (**Recording Time**) and step of checking the triggering condition (**Step**).




Figure 5-15 Recording on trigger configuration panel

5.4.8.2 Continuous recording

If Whole Measurement is chosen the panel consists only positions, where the user may select three signals for record (**Record**) from tri-axial transducer.




Figure 5-16 Continuous recording configuration panel

5.5 Working with data files

5.5.1 Downloading instrument files

If you want to download any recorded files, whatever it is: logger, wave or time domain files, you should click the **Download** button on the control area.




Figure 5-17 SV 103 Download window

Press the **Download** button, located in bottom area, and the previously selected run data files will be downloaded to local computer and the **SUPERVISOR** will enter “**Data Browser**” (see chapter [5.5.2](#)) to further manage downloaded files. Run data files in the instrument can be optionally deleted after download by checking the box under the **Download** button.

To change the working directory or scan other folders, press the “**Change dir**” button, and appropriate window will appear, see figure below.




Figure 5-18 Change instrument working directory window

5.5.2 Local files “Data Browser”

Within the **Data Browser** tab, you can see the list of previously downloaded files ready for further processing. Note that selected files will generate a short preview in the bottom area giving the operator an initial idea of the time history of the measurement results.

All files are simply divided per specific function: In the case of a instrument: hand-arm dosimetry and Wave are relevant file groups.

To further process the selected file or files, right click on selection, and choose “**New session**” command. This will bring you to the “**Session**” window (see chapter 5.6), where the reporting tool will allow you quickly and professionally review and assess the data.




Figure 5-19 Local files “Data Browser” - window layout

5.6 Working with sessions and reporting

One of the main advantages of the SUPERVISOR is its incredibly simple but professional and user customizable report creation. Once you get familiar with the power of document design you will love it and probably never come back to the old-fashioned way of reporting.

When the measurement data is downloaded via the download feature, the data is stored and viewable via the local file “**Data Browser**” window. Further work with data downloaded from instrument is based on, so called, **SESSIONS** – the most advanced charting, tables, and reporting capability in its class.

Each **SESSION** is highly configurable, and the **template** of a document once created (Figure 5-22) can be saved for future use with other measurement data. That gives the operator quick solutions at the fingertip. **The information is divided into panels** and viewable in customizable graphs and/or with selected measurement data/parameters.





Figure 5-20 SUPERVISOR main SESSION window



SESSION configuration panel enables you to see the currently selected measurement data in the “Session data” sub-panel.

“**Add panel**” contains a list of available information sections or chunks so called panels that are available to place in the report. Just double click to add a new panel section to the report detailed configuration area. Note, that each panel can be added more than once. It is possible to change the information in each panel: for example: one panel with parameters sorted in a table layout, and the other with a graph, or a zoomed graph.

**double click to
add panel to the
report**

“**Panels**” contains the list of currently added information chunks to the report detailed configuration area. Here you can change the names of the individual added panels.

**double click
to jump to
the selected panel**

“**Reports**” contains information about user generated documents saved by the software.

SESSIONS can be archived or deleted with single button click.

Figure 5-21 SESSION configuration panel




Figure 5-22 Managing templates with SUPERVISOR

5.6.1 Force threshold slider

The contact force plot is shown in the **Logger** results panel. Supervisor provides set of tools for creating automatic marker in relation to the force threshold:




Figure 5-23 Force threshold slider

Changing the value of the force threshold adjusts the marker **Force level+** for which results such as **Current Exposure** or **Vector** are calculated beneath the graph.

Selection of **Duration** enables to remove those markers which time is shorter than a set **Duration** value. The default value is 8 seconds which means that events shorter than 8 s will not be included in **Force level+** marker.

Smoothing function enables to smooth the contact force plot in order to eliminate sudden peaks in the force time history and include short contact breaks into a **Force level+** marker helping to analyze signals of the impulsive characteristics.

5.6.2 Report panels

See the following panels, then configure, and generate report.

Report options: With "**Report options**" window it is very straightforward to edit basic report information and predefined graphics, colour and style.




Figure 5-24 SUPERVISOR Report Options




Figure 5-25 Hand-Arm vibration exposure (ISO 5349-A) panel




Figure 5-26 Instrument configuration panel




Figure 5-27 Logger results panel

No	Date & time	PEAK (TH) [dB]	P-P (TH) [dB]	MAX (TH) [dB]
1	2014-05-14 07:29:05	111.8	104.6	105.4
2	2014-05-14 07:29:06	121.9	114.9	104.2
3	2014-05-14 07:29:07	110.7	104.7	103.0
4	2014-05-14 07:29:08	112.3	106.3	102.1
5	2014-05-14 07:29:09	111.0	104.7	101.6
6	2014-05-14 07:29:10	111.6	104.9	101.3
7	2014-05-14 07:29:11	111.4	105.1	101.5
8	2014-05-14 07:29:12	110.9	104.7	101.3
9	2014-05-14 07:29:13	112.2	105.3	102.0
10	2014-05-14 07:29:14	113.9	106.1	101.4
11	2014-05-14 07:29:15	111.3	105.1	101.3
12	2014-05-14 07:29:16	132.8	125.2	110.7
13	2014-05-14 07:29:17	111.9	105.4	107.5
14	2014-05-14 07:29:18	111.9	105.3	105.0
15	2014-05-14 07:29:19	111.5	105.2	102.9
16	2014-05-14 07:29:20	111.6	105.3	102.2
17	2014-05-14 07:29:21	112.5	106.0	102.5
18	2014-05-14 07:29:22	113.5	106.3	102.3
19	2014-05-14 07:29:23	111.9	105.8	102.2
20	2014-05-14 07:29:24	111.6	105.5	102.0

Figure 5-28 Logger results (table) panel

Session header	
Project name	
Author name	
Location	
User name	
Comment	

Figure 5-29 Session header panel




Figure 5-30 Configurable Text panel

Total results			
No	1		
Start date & time	2014-05-14 07:29:04		
Duration	07:53:25.000		
Name	Integration period 8 h		
L4.SVL	X	P1 (Wh)	PEAK (SR) [dB] 151.0
L4.SVL	X	P1 (Wh, Lin)	P-P (SR) [dB] 143.0
L4.SVL	X	P1 (Wh, 1 s)	MAX (SR) [dB] 132.9
L4.SVL	X	P1 (Wh, Lin)	RMS (SR) [dB] 102.8
L4.SVL	X	P2 (Band li...	PEAK (SR) [dB] 174.1
L4.SVL	X	P2 (Band li...	RMS (SR) [dB] 119.2
L4.SVL	Y	P1 (Wh)	PEAK (SR) [dB] 147.7
L4.SVL	Y	P1 (Wh, Lin)	P-P (SR) [dB] 141.3
L4.SVL	Y	P1 (Wh, 1 s)	MAX (SR) [dB] 133.2
L4.SVL	Y	P1 (Wh, Lin)	RMS (SR) [dB] 99.0
L4.SVL	Y	P2 (Band li...	PEAK (SR) [dB] 163.9
L4.SVL	Y	P2 (Band li...	RMS (SR) [dB] 114.4
L4.SVL	Z	P1 (Wh)	PEAK (SR) [dB] 151.1
L4.SVL	Z	P1 (Wh, Lin)	P-P (SR) [dB] 144.4
L4.SVL	Z	P1 (Wh, 1 s)	MAX (SR) [dB] 133.8
L4.SVL	Z	P1 (Wh, Lin)	RMS (SR) [dB] 99.7

Options Hide

<select saved view settings>

- ☒ SV 103/20140621_094407/L4.SVL
 - ☒ Summary results (SR)
 - ☒ Channel X
 - ☒ Profile 1
 - ☒ PEAK
 - ☒ P-P
 - ☒ MAX
 - ☒ RMS
 - ☒ Profile 2
 - ☒ Channel Y
 - ☒ Channel Z
 - ☐ VECTOR

Figure 5-31 Total results panel

6

SV103 MAINTENANCE

6.1 General recommendations for use

- Use only high-quality USB cables, such as SC 156. Many poor-quality cables do not ensure low resistance of the cable, thus disabling proper charging of the internal cells
- It is not recommended to leave the instrument in direct sunlight conditions for prolonged periods of time. Extended exposure such as behind the car window may affect the performance.
- To improve accuracy of remaining battery life indicator, run the instrument until it is fully discharged; then proceed with a full charge via the micro-USB port. The procedure is recommended before first use. Repeat this procedure every few months of use to maintain more accurate current battery condition indication.

6.2 Cleaning

Few things to remember:

- Every time SV 103 gets too dirty, clean the surface of the instrument with damp soft cloth.

6.3 Changing the accelerometer

To change the hand-arm triaxial accelerometer, you have to:

- turn the instrument off and disconnect it from the charger or USB,
- unfasten the connector from the mounting head,
- unscrew the connector in a counter-clockwise direction,
- attach a new accelerometer, screw the connector on clockwise until it fits tightly.



Note: The TEDS data (accelerometer serial number and calibration factor) for the accelerometer will automatically be downloaded to the SV 103 internal memory.

6.4 Firmware upgrade

SVANTEK is committed to continuous innovation path of development, and as such reserves the right to provide firmware enhancements based on user's feedback.

To update the instrument firmware:

- Unpack the provided firmware package (provided as a suitable compressed file).
- Make sure the unit is turned off.
- Hold down the **<SCROLL>**  key and press the **<ENTER>**  key to turn on the unit. This ensures the unit will switch on and enter the special reprogramming **BOOTLOADER** mode.
- Then connect the USB cable. The **<USB>** text will now appear on the instrument display.
- Run the **start.bat** file.
- Successful firmware update will be indicated by relevant message.
- Turn off the unit.



Note: With use of SUPERVISOR software, it is very easy to check if there are any new firmware releases available for download (see [Figure 5-3](#) commands).

6.5 Storing the instrument

- To preserve the life of the internal batteries, it is recommended that the SV 103 instrument is turned off when it is stored.
- Do not store the instrument permanently connected to the USB port. It shortens battery lifecycle.
- When SV 103 is turned off, it still draws a small amount of battery power. Therefore, it is recommended to charge the cell every few months if it is not going to be used regularly.

6.6 Transportation and carrying

For transportation or storage purpose, always use the packaging provided by the manufacturer. In a potentially dirty industrial environment it is advisable to use the carrying case provided by the manufacturer such as SA 73 (see chapter [2.3](#)), which ensures excellent mechanical and environmental protection and long term storage conditions.

7

SVANTEK SERVICE

7.1 Troubleshooting

1. Upon connection to the USB port, if automatic charging is not started: check the USB cable and power supply ratings of the source.
2. If the incorrect time or date is displayed when turning on the instrument connect the device to the computer and use Supervisor software to set the time and date (see) ensuring PC clock is set correctly.
3. In case the instrument is not able to turn on ensure the unit is charged by connecting to USB or recommended charger. This ensures the battery is not exhausted. Then proceed with hardware reset (chapter 7.2).
4. In case your instrument does not respond proceed with turn-off/turn-on procedure (chapter 3.8), and hardware reset of the instrument (chapter 7.2).
5. In case the measurement of the vibration level is frozen or set to a fixed value proceed with turn-off/turn-on procedure (chapter 3.8), then with hardware reset of the instrument (chapter 7.2).
6. In case the reset does not help call Local Authorized Distributor or Svantek Service Office.

7.2 Resetting the instrument

- **SYSTEM RESET:** (internal software reset clears any setup configuration and brings back the default factory settings).

See **Appendix A** for remote control commands description.

- **HARDWARE RESET:** (internal hardware reset, no user data is changed)

Make sure the battery is not exhausted, and the unit is turned off. Hold down the **<ENTER>**  key for more than 15 seconds, and then release it. Turn on the instrument as usually.



Note: Hardware reset is only to be used in extreme situations such as an instrument hang-up.

Be aware, that a hardware reset:

- will stop any pre-programmed auto-run modes
- will stop measurement run
- **HARDWARE RESET works, even if the keyboard becomes locked out!**

Should your SVANTEK professional measurement equipment need to be returned for repair or for calibration, please contact the service office at the following number or contact via the SVANTEK's website.

Service Office: +48 (22) 51-88-320 or +48 (22) 51-88-322.

Office hours are 8:00 a.m. to 4:00 p.m. Central European Time.

- E-mail: support@svantek.com
- Internet: www.svantek.com
- Address:

SVANTEK Sp. z o.o.
 Strzygłowska 81
 04-872 Warszawa,
 Poland

**Note: International customers:**

Contact your local authorized distributor from whom the product was purchased. You can obtain the name and contact information of your local authorized distributor from SVANTEK by using the e-mail or telephone information listed above or use our website to find nearest distributor office.

8

SV 103 TECHNICAL SPECIFICATION

Vibration meter

Standards	ISO 8041-:2017, ISO 5349-1:2001; ISO 5349-2:2001
Meter mode	RMS, Max, Peak, Peak-Peak, Vector, A(8) Daily Dose, ELV, EAV Simultaneous measurement in three channels
Filters	Wh (ISO 5349) and corresponding Band Limiting filter
RMS & RMQ Detectors	Digital true RMS & RMQ detectors with Peak detection, resolution 0.1 dB
Measurement Range	0.2 ms ⁻² RMS ÷ 2000 ms ⁻² PEAK
Frequency Range	1 Hz ÷ 2000 Hz
Data Logger	Time-history data including meter mode results and spectra
Time-Domain Recording	Simultaneous 3-channel time-domain signal recording (option)
Analyser	1/1 octave real-time analysis meeting Class 1: IEC 61260 (option) 1/3 octave real-time analysis meeting Class 1: IEC 61260 (option)
Accelerometer	detachable SV 107 tri-axial accelerometer with hand straps in accordance to ISO 5349

Basic data

Display	OLED 128 x 64 pixels
Memory	8 GB
Interfaces	USB 2.0 client
Keyboard	4 push buttons
Power Supply	Ni-MH rechargeable cells: operation time > 24 hours ¹
USB interface	500 mA HUB
Environmental Conditions	Temperature: from -10°C to 50°C Humidity: up to 90% RH, non-condensed
Dimensions	88 x 49.5 x 19.2 mm (instrument without accelerometer, cable and mounting stripe)
Weight adapters	150-160 grams with SV 107 accelerometer and one of vibration contact

¹ depends on instrument operation mode